




**G-PROFILE
MOVING HEAD**



Dimensions



*Measurements in millimetres
and inches (in brackets).
Drawing not to scale.*

G-PROFILE

USER MANUAL

© 2015 SGM®. Information subject to change without notice. SGM and all affiliated companies disclaim liability for any injury, damage, direct or indirect loss, consequential or economic loss or any other loss occasioned by the use of, inability to use or reliance on the information contained in this manual.

The SGM logo, the SGM name and all other trademarks in this document pertaining to services or products by SGM or its affiliates and subsidiaries are trademarks owned or licensed by SGM or its affiliates or subsidiaries.

The original edition of this document is in English. All other language editions are translations of the original edition.

This edition applies to firmware version 1.30 or later.

Ver. A

Contents

Dimensions	2
Safety information	7
Overview	10
Unpacking	11
<i>Transportation</i>	11
Installation / Rigging	12
Connecting AC power	14
Control panel operations	15
<i>Using the control panel</i>	15
<i>DMX start address</i>	15
<i>Selecting module (G-Profile or G-Spot)</i>	15
<i>Configuring the device using an Android telephone via RFID</i>	16
Connecting to a DMX control device	17
Configuring the device for DMX control	18
<i>About DMX</i>	18
<i>Setting the DMX address</i>	18

Control panel menus	19
Gobo replacement	28
Identification of gobo wheel	28
Replacing rotating gobo	29
How to replace a gobo in a gobo holder	30
Maintenance	31
Upgrading the firmware	31
Cleaning	31
DMX protocols	32
Standard Mode	32
Extended Mode	44
Effects	56
Four individually controllable framing blades	56
Independent rotating gobo wheel	56
Combination of framing techniques and rotating gobos	56
Effect wheel	57
High-precision pan and tilt	57
Ultra high-speed strobe effect	57
Prism	57
Frost	57

Fixtures and accessories	58
<i>Included items</i>	58
<i>Ordering information</i>	58
User's notes	60

Safety information



WARNING! Read the safety precautions in this section before unpacking, installing, powering or operating this product.

The G-Profile is intended for professional use only. It is not suitable for household use. ***Impropre à l'usage domestique.***

Review the following safety precautions carefully before installing or operating the fixture.

This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved. **Ce produit doit être installé selon le code d'installation pertinent, par une personne qui connaît bien le produit et son fonctionnement ainsi que les risques inhérent.**

Preventing electric shock



WARNING! Risk of electric shock.

- Always power off/unplug the fixture before removing covers or dismantling product.
- Ensure that the mains power is off when wiring the fixture to the AC mains supply.
- Ensure that the fixture is electrically connected to earth (ground).
- Do not apply power if the fixture is in any way damaged.
- Do not immerse the fixture in water or liquid.

Preventing burns and fire



WARNING! Take measures to prevent burns and fire.

- Install in a location that prevents accidental contact with the fixture.
- Install only in a well-ventilated space.
- Install at least 0.3 m (12 in.) away from objects to be illuminated.
- Install only in accordance with applicable building codes.
- Ensure a minimum clearance of 0.1 m (4 in.) around the cooling fans.
- Do not paint, cover or modify the fixture.
- Keep all flammable materials away from the fixture.
- Allow the fixture to cool for 15 minutes after operation, before touching it.

CAUTION: Exterior surface temperature after 5 min. operation = 55° C (131° F). Steady state = 65° C (149° F)

Avoid personal injury




WARNING! Take measures to prevent personal injury.

- Do not look directly at the light source from close range.
- Take precautions to prevent injury when working at height.
- Ensure that the fixture is always securely fastened with suitable hardware.
- For elevated installations, secure the fixture with suitable safety cables, and always comply with relevant load dimensioning, safety standards and requirements.

Overview

The SGM G-Profile model is a framing version of the G-Spot Moving Head. The G-Profile is a maintenance free, multi-environmental fixture with an IP-rating of 65. It has a powerful LED light source, and a virtually unlimited color palette, four individually controllable framing blades, and can easily be controlled by wired and wireless DMX. The fixture also offers RFID and NFC, low power consumption and an expected lifetime of the multiple LED's of 50,000 hours*.

- A : Pan lock
- B : Tilt lock
- C : Yoke handle
- D : Base handle
- E : Head fan grill (one of two shown)
- F : Display panel
- G : Safety wire attachment point
- H : Fuse
- I : DMX in
- J : DMX out
- K : Power in
- L : Power cord



* At 70% of luminous output under the manufacturer's test conditions.

Unpacking

Unpack the fixture and inspect it to ensure that it has not been damaged in transport.

The G-Profile is supplied with:

- User manual.
- One Neutrik TRUE1 power input connector, 2 m (78 in.)
- Two Omega brackets with 1/4-turn fasteners.

The fixture is designed for use in wet locations and is IP65-rated. When selecting a location for the fixture, ensure that:

- it is situated away from public throughfares and protected from contact with people.
- it has adequate ventilation.

Transportation

Always use the supplied packaging for transportation and storage.

Release the pan/tilt locks when transporting the fixture. Leaving the pan/tilt locks applied may cause damage to the fixture.

Installation / Rigging



WARNING! Always secure elevated fixtures with a safety cable.



The G-Profile may be installed in any orientation.

Always use two Omega brackets to rig the fixture. Lock each bracket with both 1/4-turn fasteners. The fasteners are locked only when turned fully clockwise.

Always fasten safety cables between the load-bearing support structure and the attachment points on the fixture. The safety cables must be able to bear at least 10 times the weight of the fixture.



CAUTION:

- Always use 2 safety wires.
- Min. safety wire gauge = 5 mm.
- Max. safety wire length (free fall) = 30 cm (11 in.).
- Make sure the slack of the safety wire is at a minimum.
- Never use the carrying handles for secondary attachment.



Start the rigging process by blocking the work area below, and make sure the work is performed from a stable platform.

- 1 Check that the clamps are undamaged and can bear at least 10 times the weight of the fixture. Check that the structure can bear at least 10 times the weight for all installed fixtures, clamps, cables etc.
- 2 Bolt each clamp securely to an Omega bracket with an M12 / $\frac{1}{2}$ " bolt (min. grade 8.8) and lock nut.
- 3 Align an Omega bracket with two 1/4-turns in the base. Insert the fasteners into the base and turn both levers a full 1/4-turn clockwise to lock. Install the second Omega bracket.
- 4 Working from a stable platform, hang the fixture on a truss, or other structure. Note the position of the base. The front of the base is to the right, when looking at the display panel, and when the fixture is sitting on the base. Tighten the clamps.
- 5 Install two safety wires that each can bear at least 10 times the weight of the unit. The attachment points are designed to fit a carabiner.
- 6 Check that the pan/tilt locks are released (A and B). Verify that there are no combustible materials or surfaces to be illuminated within 0.3 m (12 in.) of the fixture.
- 7 Check that there is no possibility of head or yoke colliding with other fixtures.



Connecting AC power

The G-Profile can operate on any 200-240V, 50/60 Hz mains power supply.



Connect the fixture to power using a cable with a Neutrik powerCON TRUE1 connector (supplied with the fixture). Connect both DMX in and DMX out cables in order to maintain the fixture IP65.

The fixture must be grounded/earthed and be able to be isolated from AC power. The AC power supply must incorporate a fuse or circuit breaker for fault protection.

- Connect the black wire to live
- Connect the white wire to neutral
- Connect the green wire to ground (earth)

After connecting the G-Profile to power, run the on-board test, using the “Test→LED Test” menu, to ensure that the fixture is functioning correctly. See “Control panel menus” on page 19.

Wire	Color	Symbol	Conductor
	Black	L	live
	White	N	neutral
	Green	\pm or	ground (earth)




Control panel operations

You can configure individual fixture settings, read out data and view error messages in the graphic display. When the fixture is powered on, it boots and resets, then displays the DMX start address and any status messages.

Using the control panel

- Click the arrow buttons to scroll up and down menus.
- Click the OK button to enter a menu or make a selection.
- Press the ESC button to step backwards through the menus.



DMX start address

The DMX start address is the first channel used to receive instructions from the controller. For independent control, each fixture must be assigned its own control channels. If you give two fixtures the same address, they will behave identically. Address sharing can be useful for diagnostic purposes and symmetrical control.

Select DMX address using the arrow buttons.

Selecting module (G-Profile or G-Spot)

If you replace the fixture's module in order to switch from a G-Profile to a G-Spot or vice-versa, you need to change the fixture's software settings.

In the Control Menu, go to 'Settings→Service Menu→Fixture Type' and select the fixture you are currently using.

NOTE: To access "Service Menu→Fixture Type", you need to type in the value '0110' under 'Settings→Service Pin'. See "Control panel menus" on page 19 for more details.

Configuring the device using an Android telephone via RFID

The G-Profile can also be configured wirelessly, via RFID, using the SGM Tool app installed on an Android smart phone that has NFC support (ISO 15693 and ISO 18000-3 mode 1 compatible, operating on 13.56 MHz $\pm 7\text{kHz}$ carrier frequency).

Connecting to a DMX control device

The G-Profile is controllable using a DMX control device and it can be connected using either a DMX cable or via the fixture's built-in LumenRadio CRMX wireless receiver system.

If using a cabled DMX system, connect the DMX in cable (with male 5-pin XLR plug) and out cable (with female 5-pin XLR plug) to the DMX data link. Terminate the DMX out cable of the last fixture in the data link. For outdoor installations, use only IP-rated XLR connectors suitable for outdoor use.

Configuring the device for DMX control

About DMX

The G-Profile can be controlled using signals sent by a DMX controller on a number of channels (which varies depending on the DMX mode that has been set).

The first channel used to receive data from a DMX control device is known as the DMX start address. Each G-Profile must have a DMX start address set. For example, if a fixture has a DMX address of 10 and it is in 3-channel DMX mode, then it uses channels 10, 11, and 12. The following device in the DMX chain could then be set to a DMX address of 13. If two or more DMX devices of the same type have the same DMX address, then they will mimic each other's behavior. Incorrect settings will result in unpredictable responses to the lighting controller.

Setting the DMX address

The DMX address can be seen on the OLED display. To change the address setting, press the up and down arrows. When the desired address is displayed, press 'OK' to save the setting. For your convenience, the suggested DMX address of the next device is displayed to the right. Note that channel spacing is determined by the DMX mode.

See the "DMX protocols" on page 32 for specific DMX control values.

Control panel menus

Level 1	Level 2	Level 3	Level 4	Info
DMX MODE	STANDARD			
	EXTENDED			
INFO	GENRAL INFO	PRODUCT: SN: RDM LABEL RDM ID		
	SOFTWARE VERSION	MAIN: SMPS: PAN: TILT: GOBO: ZOOM:		

Level 1	Level 2	Level 3	Level 4	Info
INFO (continued)	TIMERS	RED GREEN BLUE RUNNING HOURS	D: H: D: H: D: H: D: H:	
	DMX VIEW	001 - ↓ 507 -		
	TEMPERATURES	LED SMPS PAN: GOBO: BASE: HUMIDITY	R: G: B: TILT: FOCUS: HEAD: B: H:	
	SENSORS			

Level 1	Level 2	Level 3	Level 4	Info
INFO (continued)	FANS	LED FAN 1: LED FAN 2: HEAD: BASE:	rpm rpm rpm rpm	
	LOG	FIRMWARE: BUILD: BUILD: UPTIME:	D: H: M: S:	
	ERRORS	SMPS PAN TILT GOBO ZOOM		

Level 1	Level 2	Level 3	Level 4	Info
SETTINGS	WIRELESS DMX	LOG OFF		
		STATUS	SIGNAL STRENGHT % CRMX PAIRD: RDM ACTIVE: DMX ACTIVE: CRMX RATE Hz	
		ENABLE/DISABLE		
		CRMX → DMX		

Level 1	Level 2	Level 3	Level 4	Info
SETTINGS (continued)	DIMMING CURVE	LINEAR () GAMMA CORRECTED (X)		
	INVERT PAN ()			
	INVERT TILT ()			
	SWAP PAN TILT ()			
	FLIP DISPLAY ()			
	DISPLAY OFF ()			
	FAN MODE	STANDARD SILENT MAX POWER ALWAYS 100%		

Level 1	Level 2	Level 3	Level 4	Info
SETTINGS (continued)	CALIBRATION	PAN HOME	CALIBRATION → XXXXX PAN POS XXXX - REV. X.XX	
		TILT HOME	CALIBRATION → XXXXX PAN POS XXXX - REV. X.XX	
		GOBO SELECT	CALIBRATION → XXXXX	
		EFFECT WHEEL	CALIBRATION → XXXXX	

Level 1	Level 2	Level 3	Level 4	Info
SETTINGS (continued)	CALIBRATION (continued)	FROST	CALIBRATION → XXXXX	
		PRISM	CALIBRATION → XXXXX	
		IRS	CALIBRATION → XXXXX	
		ZOOM	CALIBRATION → XXXXX	
		FOCUS	CALIBRATION → XXXXX	
	SERVICE PIN			
	SERVICE MENU	FIXTURE TYPE		
		DEBUG		


Level 1	Level 2	Level 3	Level 4	Info
SETTINGS (continued)	FACTORY DEFAULT	FACTORY DEFAULT SET		
TEST	OFF			
	AUTOMATED TEST			
	LED TEST	TESTING RED 2		
		TESTING RED 1		
		TESTING BLUE 2		
		TESTING BLUE 1		
		TESTING YELLOW		
		TESTING GREEN		
	DISPLAY TEST			

Level 1	Level 2	Level 3	Level 4	Info
RESET¹	PAN TILT			
	EFFECT MODULE			
	ZOOM FOCUS MODULE			
	ALL			

1. If the G-Profile is subjected to extreme exposure, the fixture might not reset correctly. If this happens, the fixture will automatically heat up the gobo bearings at maximum light output for approx. five minutes and attempt to reset the fixture again. Should this not resolve the issue, disconnect the fixture from power, and power it back on again to repeat the heat-up procedure. Should this not solve the issue, contact your local SGM distributor or SGM Technical Support. See <http://sgmlight.com/service-aftersales/> for more details.

Gobo replacement

Identification of gobo wheel





No.	Description	Part No.
Open	Open gobo	37000001
1	Breakup bricks	37005006
2	Dots	37005003
3	Fire up close	37005001
4	Spiral leaf	37005010
5	Kaleidoscope gems	37002001

Replacing rotating gobo




To replace a gobo:

- Disconnect the fixture from power and allow to cool.
- Position the head and apply the tilt lock.
- Remove the rear head cover located on the same side as the pan lock (A). See figure below.
- Remove the gobo wheel cover for access to the gobo wheel.
- Turn the gobo wheel until the gobo you want to replace is accessible.
- Unhook the end of the spring and turn it upwards. Pull the gobo holder out of the gobo wheel.



How to replace a gobo in a gobo holder

- Place gobo with silver side towards the light source.
- Align index markers on the gobo and the gobo holder as shown below.
- Insert the gobo holder and align it with the index marker on the gobo wheel as shown below. If necessary, continue replacing gobos one by one as described above. If no further service is necessary, reinstall the gobo wheel cover. To maintain the fixture's IP65 rating, it is important to fasten the gobo covers to 1 Nm.



Maintenance

When cleaning the fixture, do not use any product that contains abrasives or solvents that can damage plastic or painted surfaces. Use a clean cloth with water and a standard household cleaner.

To maintain adequate cooling, fans must be cleaned periodically.

Upgrading the firmware

The firmware installed on the fixture can be identified using the “Info→Software version” menu. We recommend that you keep your fixture’s firmware up-to-date. Visit <http://www.sgmlight.com> to download the latest firmware.

To perform firmware updates, you need a Windows-based personal computer and a SGM USB 5-Pin-XLR upload cable (available from your SGM distributor).

Cleaning

To maintain optimal performance, regular cleaning is essential. Cleaning schedules will vary greatly depending on the operating environment, and the installation should therefore be checked at frequent intervals within the first few weeks of operation to see whether cleaning is necessary. This procedure will allow you to assess cleaning requirements in your particular situation. If in doubt, consult your SGM dealer for a suitable maintenance schedule.

Setting the OLED display saver

By default the OLED display dims down after a short period when the control panel is not in use, but it can also be set to turn off completely. Pressing any key will always turns on the display or restore it to normal brightness. To change the display saver, use the “Settings→Display Off” menu.

NOTE: To avoid the risk of display deterioration caused by long term use in permanent installations, it is recommended to use the “Settings→Display Off” setting.

DMX protocols

Standard Mode

31 Channel Mode (Standard)								
Channel	Name	DMX Value	DMX Percentage		Description	Info	Default DMX Value	Fader Type
1	Shutter	0	7	0,0% 2,7%	Closed		10 (3,9%)	Snap
		8	15	3,1% 5,9%	Open			
		16	151	6,3% 59,2%	Strobe	Slow > Fast		
		152	175	59,6% 68,6%	Pulse - Open	Slow > Fast		
		176	199	69,0% 78,0%	Pulse - Close	Slow > Fast		
		200	244	78,4% 95,7%	Strobe - Random	Slow > Fast		
		245	255	96,1% 100,0%	Open			
2	Intensity	0	255	0,0% 100,0%	No light > Maximum light		0 (0%)	Fade
3	Red	0	255	0,0% 100,0%	No RED > Maximum RED		0 (0%)	Fade

31 Channel Mode (Standard)

Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type
4	Green	0 255	0,0% 100,0%	No GREEN > Maximum GREEN		0 (0%)	Fade
5	Blue	0 255	0,0% 100,0%	No BLUE > Maximum BLUE		0 (0%)	Fade
6	CTC	0 4	0,0% 1,6%	No CTC			
		5 5	2,0% 2,0%	≈ 2000° K			
		15 15	5,9% 5,9%	≈ 2200° K (High Pressure Sodium Lamp)			
		40 40	15,7% 15,7%	≈ 2700° K (Incandescent Lamp)			
		54 54	21,2% 21,2%	≈ 3000° K (Halogen / Tungsten Lamp)			

31 Channel Mode (Standard)

Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type
6	CTC	65	25,5%	≈ 3200° K (Warm Metal Halide Lamp)		0(0%)	Fade
		105	41,2%	≈ 4000° K (Clear Metal Halide Lamp)			
		115	45,1%	≈ 4200° K (Cool White Fluorescent Lamp)			
		177	69,4%	≈ 5500° K (Daylight Metal Halide Lamp)			
		216	84,7%	≈ 6300° K			
		238	93,3%	≈ 8000° K			
		255	100,0%	≈ 10,000° K			

31 Channel Mode (Standard)

Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type
7 8	Pan	0 65535	0,0% 100,0%	-270° to 270°	-270° = Front Lens @ Mains Power Input (Tilt=0)	32767 (50%)	Fade
9 10	Tilt	0 65535	0,0% 100,0%	-120° to 120°	-120° = Front Lens @ Base Front (Pan=32767)	32767 (50%)	Fade
11	Gobo Wheel 1	0 20	0,0% 7,8%	Open		0 (%)	Snap
		21 41	8,2% 16,1%	Gobo 1 - Position 1			
		42 62	16,5% 24,3%	Gobo 1 - Position 2			
		63 83	24,7% 32,5%	Gobo 1 - Position 3			
		84 104	32,9% 40,8%	Gobo 1 - Position 4			
		105 127	41,2% 49,8%	Gobo 1 - Position 5			

31 Channel Mode (Standard)

Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type	
11	Gobo Wheel 1	128	191	50,2% 74,9%	Gobo Wheel Continuous Rotation CW	Fast > Slow	0 (0%)	Snap
		192	192	75,3% 75,3%	No Rotation			
		193	255	75,7% 100,0%	Gobo Wheel Continuous Rotation CCW	Slow > Fast		
12 13	Gobo Wheel 1 Indexing Rotation Shake	0	32767	0,0% 50,0%	Gobo Index		0 (0%)	Fade
		32768	32799	50,0% 50,0%	No Effect			
		32800	46418	50,0% 70,8%	Gobo Continuous Rotation CW	Fast > Slow		
		46419	46919	70,8% 71,6%	No Rotation			

31 Channel Mode (Standard)

Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type	
12 13	Gobo Wheel 1 Indexing Rotation Shake	46920	60538	71,6% 92,4%	Gobo Continuous Rotation CW	Slow > Fast	0 (0%)	Fade
		60539	65535	92,4% 100,0%	Gobo Shake	Slow >Fast		
14	Blade 1 In	0	255	0,0% 100,0%	Blade 1 In	Out >In	0 (0%)	Fade
15	Blade 1 Angle	0	255	0,0% 100,0%	Blade 1 Angle	-30° > +30°	128 (50%)	Fade
16	Blade 2 In	0	255	0,0% 100,0%	Blade 2 In	Out >In	0 (0%)	Fade
17	Blade 2 Angle	0	255	0,0% 100,0%	Blade 2 Angle	-30° > +30°	128 (50%)	Fade
18	Blade 3 In	0	255	0,0% 100,0%	Blade 3 In	Out >In	0 (0%)	Fade
19	Blade 3 Angle	0	255	0,0% 100,0%	Blade 3 Angle	-30° > +30°	128 (50%)	Fade

31 Channel Mode (Standard)

Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type
20	Blade 4 In	0 255	0,0% 100,0%	Blade 4 In	Out >In	0 (0%)	Fade
21	Blade 4 Angle	0 255	0,0% 100,0%	Blade 4 Angle	-30° > +30°	128 (50%)	Fade
22	Blade Assembly Rotate	0 255	0,0% 100,0%	Blade Assembly Rotate	-45° > +45°	128 (50%)	Fade
23 24	Effect Wheel	0 511	0,0% 0,8%	Open		0 (0%)	Fade
		512 2559	0,8% 3,9%	Inserted Not Indexed			
		2560 32767	3,9% 50,0%	Indexed			

31 Channel Mode (Standard)

Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type
23 24	Effect Wheel	32768 46402	50,0% 70,8%	Continuous Rotation CW	Fast > Slow	0 (0%)	Fade
		46403 46903	70,8% 71,6%	Stop			
		46904 60538	71,6% 92,4%	Continuous Rotation CCW	Slow >Fast		
		60539 65535	92,4% 100,0%	Reserved (Calibration Position)			
25	Iris	0 200	0,0% 78,4%	Open > Close		0 (0%)	Fade
		201 205	78,8% 80,4%	Effect - "Open fast / Close slow"			
		206 210	80,8% 82,4%	Effect - "Open slow / Close fast"			

31 Channel Mode (Standard)

Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type
25	Iris	211	215	82,7% 84,3%	Effect - "Open / Close"	0 (0%)	Fade
		216	255	84,7% 100,0%	Effect - "Random Close / Open"		
26	Prism	0	4	0,0% 1,6%	Open	0 (0%)	
		5	129	2,0% 50,6%	Continuous Rotation CW	Fast > Slow	
		130	130	51,0% 51,0%	No Rotation		
		131	255	51,4% 100,0%	Continuous Rotation CCW	Slow > Fast	
27	Frost	0	5	0,0% 2,0%	Open	0 (0%)	Fade
		6	255	2,4% 100,0%	No Frost > Maximum Frost		
28	Zoom	0	255	0,0% 100,0%	Wide > Narrow	0 (0%)	Fade

31 Channel Mode (Standard)

Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type
29	Focus	0 255	0,0% 100,0%	Far > Near		0 (0%)	Fade
30	Effect Channel	0 4	0,0% 1,6%	No Effect		0 (0%)	Snap
		5 15	2,0% 5,9%	Reserved (No Effect)			
		16 26	6,3% 10,2%	Reserved (No Effect)			
		27 32	10,6% 12,5%	Shutter Black = RED			
		33 38	12,9% 14,9%	Shutter Black = GREEN			
		39 44	15,3% 17,3%	Shutter Black = BLUE			
		45 50	17,6% 19,6%	Shutter Black = WHITE			
		51 56	20,0% 22,0%	Shutter Black = Magenta			
		57 62	22,4% 24,3%	Shutter Black = Yellow			
		63 68	24,7% 26,7%	Shutter Black = Cyan			

31 Channel Mode (Standard)								
Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type	
30	Effect Channel	69 255	27,1% 100,0%	Reserved (No Effect)		0 (0%)	Snap	
31	Control Channel	0 4	0,0% 1,6%	No Function		0 (0%)	Snap	
		5 9	2,0% 3,5%	Full Reset	Hold 3 seconds			
		10 14	3,9% 5,5%	Pan Reset	Hold 3 seconds			
		15 19	5,9% 7,5%	Tilt Reset	Hold 3 seconds			
		20 24	7,8% 9,4%	Gobo Reset	Hold 3 seconds			
		25 29	9,8% 11,4%	Zoom Reset	Hold 3 seconds			

31 Channel Mode (Standard)

Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type	
31	Control Channel	30	34	11,8% 13,3%	Sleep Mode	See note ¹	0 (0%)	Snap
		35	39	13,7% 15,3%	Display Off	Hold 3 seconds		
		40	44	15,7% 17,3%	Display On	Hold 3 seconds		
		45	255	17,6% 100,0%	Reserved (No Function)			

1. All other channels must be zero and this has to be held for 30 sec. (fixture will wake up on a full reset).

Extended Mode

46 Channel Mode (Extended)								
Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type	
1	Shutter	0 7	0,0% 2,7%	Closed		10 (3,9%)	Snap	
		8 15	3,1% 5,9%	Open				
		16 151	6,3% 59,2%	Strobe	Slow > Fast			
		152 175	59,6% 68,6%	Pulse - Open	Slow > Fast			
		176 199	69,0% 78,0%	Pulse - Close	Slow > Fast			
		200 244	78,4% 95,7%	Strobe - Random	Slow > Fast			
		245 255	96,1% 100,0%	Open				
2	Intensity	0 65535	0,0% 100,0%	No light > Maximum light		0 (0%)		
3								
4	Red	0 65535	0,0% 100,0%	No RED > Maximum RED		0 (0%)		
5								

46 Channel Mode (Extended)

Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type
6 7	Green	0 65535	0,0% 100,0%	No GREEN > Maximum GREEN		0 (0%)	
8 9	Blue	0 65535	0,0% 100,0%	No BLUE > Maximum BLUE		0 (0%)	
10	CTC	0 4	0,0% 1,6%	No CTC		0(0%)	Fade
		5 5	2,0% 2,0%	≈ 2000K			
		15 15	5,9% 5,9%	≈ 2200K (High Pressure Sodium Lamp)			
		40 40	15,7% 15,7%	≈ 2700K (Incandescent Lamp)			
		54 54	21,2% 21,2%	≈ 3000K (Halogen / Tungsten lamp)			

46 Channel Mode (Extended)

Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type
10	CTC	65	25,5%	≈ 3200K (Warm Metal Halide Lamp)		0(0%)	Fade
		105	41,2%	≈ 4000K (Clear Metal Halide Lamp)			
		115	45,1%	≈ 4200K (Cool White Fluorescent Lamp)			
		177	69,4%	≈ 5500K (Daylight Metal Halide Lamp)			
		216	84,7%	≈ 6300K			
		238	93,3%	≈ 8000K			
		255	100,0%	≈ 10,000K			

46 Channel Mode (Extended)

Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type
11 12	Pan	0 65535	0,0% 100,0%	-270° to 270°	-270° = Front Lens @ Mains Power Input (Tilt=0)	32767 (50%)	Pan
13 14	Tilt	0 65535	0,0% 100,0%	-120° to 120°	-120° = Front Lens @ Base Front (Pan=32767)	32767 (50%)	Tilt
15	Gobo Wheel 1	0 20	0,0% 7,8%	Open		0(0%)	Snap
		21 41	8,2% 16,1%	Gobo 1 - Position 1			
		42 62	16,5% 24,3%	Gobo 1 - Position 2			
		63 83	24,7% 32,5%	Gobo 1 - Position 3			
		84 104	32,9% 40,8%	Gobo 1 - Position 4			
		105 127	41,2% 49,8%	Gobo 1 - Position 5			

46 Channel Mode (Extended)

Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type	
15	Gobo Wheel 1	128	191	50,2% 74,9%	Gobo Wheel Continuous Rotation CW	Fast > Slow	0(0%)	Snap
		192	192	75,3% 75,3%	No Rotation			
		193	255	75,7% 100,0%	Gobo Wheel Continuous Rotation CCW	Slow > Fast		
16 17	Gobo Wheel 1 Indexing Rotation Shake	0	32767	0,0% 50,0%	Gobo Index		0(0%)	Fade
		32768	32799	50,0% 50,0%	No Effect			
		32800	46418	50,0% 70,8%	Gobo Continuous Rotation CW	Fast > Slow		
		46419	46919	70,8% 71,6%	No Rotation			
		46920	60538	71,6% 92,4%	Gobo Continuous Rotation CCW	Slow > Fast		

46 Channel Mode (Extended)									
Channel	Name	DMX Value		DMX Percentage		Description	Info	Default DMX Value	Fader Type
16 17	Gobo Wheel 1 Indexing Rotation Shake	60539 65535		92,4%	100,0%		Slow > Fast	0(0%)	Fade
18 19	Blade 1 In	0	65535	0,0%	100,0%	Blade 1 In	Out >In	0(0%)	Fade
20 21	Blade 1 Angle	0	65535	0,0%	100,0%	Blade 1 Angle	-30° > +30°	32767 (50%)	
22 23	Blade 2 In	0	65535	0,0%	100,0%	Blade 2 In	Out >In	0(0%)	
24 25	Blade 2 Angle	0	65535	0,0%	100,0%	Blade 2 Angle	-30° > +30°	32767 (50%)	
26 27	Blade 3 In	0	65535	0,0%	100,0%	Blade 3 In	Out >In	0(0%)	

46 Channel Mode (Extended)								
Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type	
28 29	Blade 3 Angle	0 65535	0,0% 100,0%	Blade 3 Angle	-30° > +30°	32767 (50%)	Fade	
30 31	Blade 4 In	0 65535	0,0% 100,0%	Blade 4 In	Out >In	0(0%)		
32 33	Blade 4 Angle	0 65535	0,0% 100,0%	Blade 4 Angle	-30° > +30°	32767 (50%)		
34 35	Blade Assembly Rotate	0 65535	0,0% 100,0%	Blade Assembly Rotate	-45° > +45°	32767 (50%)		
36 37	Effect Wheel	0 511	0,0% 0,8%	Open		0(0%)	Fade	
		512 2559	0,8% 3,9%	Inserted Not Indexed				
		2560 32767	3,9% 50,0%	Indexed				
		32768 46402	50,0% 70,8%	Continuous Rotation CW	Fast > Slow			

46 Channel Mode (Extended)

Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type	
36 37	Effect Wheel	46403	46903	70,8% 71,6%	Stop		0(0%)	Fade
		46904	60538	71,6% 92,4%	Continuous Rotation CCW	Slow > Fast		
		60539	65535	92,4% 100,0%	Reserved (Calibration Position)			
38	Iris	0	200	0,0% 78,4%	Open > Close		0 (0%)	Fade
		201	205	78,8% 80,4%	Effect - “Open fast / Close slow”			
		206	210	80,8 82,4%	Effect - “Open slow / Close fast”			
		211	215	82,7% 84,3%	Effect - “Open / Close”			
		216	255	84,7% 100,0%	Effect - “Random Close / Open”	Slow > Fast		

46 Channel Mode (Extended)									
Channel	Name	DMX Value		DMX Percentage		Description	Info	Default DMX Value	Fader Type
39	Prism	0	4	0,0%	1,6%	Open		0(0%)	Fade
		5	129	2,0%	50,6%	Continuous Rotation CW	Fast > Slow		
		130	130	51,0%	51,0%	No Rotation			
		131	255	51,4%	100,0%	Continuous Rotation CCW	Slow > Fast		
40	Frost	0	5	0,0%	2,0%	Open		0 (0%)	Fade
		6	255	2,4%	100,0%	No Frost > Maximum Frost			
41 42	Zoom	0	65535	0,0%	100,0%	Wide > Narrow		0 (0%)	Fade
43 44	Focus	0	65535	0,0%	100,0%	Far > Near		0 (0%)	Fade

46 Channel Mode (Extended)

Channel	Name	DMX Value	DMX Percentage		Description	Info	Default DMX Value	Fader Type
45	Effect Channel	0	4	0,0%	1,6%	No Effect	0 (0%)	Snap
		5	15	2,0%	5,9%	Reserved (No Effect)		
		16	26	6,3%	10,2%	Reserved (No Effect)		
		27	32	10,6%	12,5%	Shutter Black = RED		
		33	38	12,9%	14,9%	Shutter Black = GREEN		
		39	44	15,3%	17,3%	Shutter Black = BLUE		
		45	50	17,6%	19,6%	Shutter Black = WHITE		
		51	56	20,0%	22,0%	Shutter Black = Magenta		
		57	62	22,4%	24,3%	Shutter Black = Yellow		
		63	68	24,7%	26,7%	Shutter Black = Cyan		
		69	255	27,1%	100,0%	Reserved (No Effect)		

46 Channel Mode (Extended)

Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type
46	Control Channel	0 4	0,0% 1,6%	No Function		0(0%)	Snap
		5 9	2,0% 3,5%	Full Reset	Hold 3 seconds		
		10 14	3,9% 5,5%	Pan Reset	Hold 3 seconds		
		15 19	5,9% 7,5%	Tilt Reset	Hold 3 seconds		
		20 24	7,8% 9,4%	Gobo Reset	Hold 3 seconds		
		25 29	9,8% 11,4%	Zoom Reset	Hold 3 seconds		
		30 34	11,8% 13,3%	Sleep Mode	See note ¹		

46 Channel Mode (Extended)


Channel	Name	DMX Value	DMX Percentage	Description	Info	Default DMX Value	Fader Type
46	Control Channel	35 39	13,7% 15,3%	Display Off	Hold 3 seconds	0(0%)	Snap

1. All other channels must be zero and this has to be held for 30 sec. (fixture will wake up on a full reset).

Effects

Four individually controllable framing blades

The four individually controllable framing blades are each adjustable ± 30 degrees while the module is rotatable through ± 45 degrees. The framing blades allows the G-Profile to perform beam-shaping images and projections (see examples below) and “DMX protocols” on page 32 for more details.



Independent rotating gobo wheel

The independent rotating gobo wheel has five slots plus one open position to control the shape of emitted light. The gobo is indexable with bi-directional rotation. The standard gobo includes both breakup patterns, geometric gobos and full colored gobos.

Combination of framing techniques and rotating gobos

The G-Profile provides the option of combining framing techniques with 5 rotating gobos and opens for gobo animation and interaction when framing is used.

Effect wheel

The G-Profile has an effect wheel for generating optical effect. The effect wheel features continuous rotation with variable speed and direction.

High-precision pan and tilt

The G-Profile has a 16-bit pan and tilt control, with a 540° pan and 270° tilt movement with feedback.

Ultra high-speed strobe effect

The ultra high-speed strobe effect (1-50 Hz) introduces instant color control and the possibility to strobe between two or more colors at any speed by. Random strobe and pulse effects can be generated with variable speed.

Prism

4-facet rotating prism.

Frost

The soft high-quality frost filter is variable from 0% to 100%.

Fixtures and accessories

Included items

Two Omega brackets with 1/4-turn fasteners
2 m power cable with Neutrik TRUE1 power connector
User manual

Ordering information

G-Profile Moving Head in cardboard box	Order no: 80021010
G-Profile Moving Head in flight case (1 fixture).....	Order no: 80021011
SGM USB uploader cable	Order no: 83062011
2 m power cable with Neutrik TRUE1 power connector.....	Order no: 07860040
Flight case (1 fixture).....	Order no: 82051003

APPROVALS AND CERTIFICATIONS

Conforms to	2004/108/EC: EMC Directive
Conforms to	2006/95/EC: Low Voltage Directive
Conforms to	2011/65/EU: RoHS2 Directive
Conforms to	UL Std.1573
Certified to	CSA E60598-1:02, Ed: 2
Certified to	CSA-E598-2-17-98, Ed: 1



RoHS

The information in this document is subject to change without notice

User's notes



Distributor:



www.techni-lux.com

Phone: 407-857-8770
Fax: 407-857-8771
Email: sales@techni-lux.com